DURACELL® CEF24NC
Rechargeable

- *Compact/portable convenience*
- *Safety protections and controls*
- *Foldable Plug*

Ideal for Digital and High-Drain Devices

CORRECT DISPOSAL OF THIS PRODUCT

Please follow any local requirements to recycle used electronic appliances and rechargeable batteries. Used rechargeable batteries may be recycled at no cost to the consumer through the retail collection sites maintained by the Rechargeable Battery Recycling Corporation (www.rbrc.org)

If you would like additional information on Duracell Rechargeable Batteries call 1-800-551-2355 (9:00AM-5:00PM E.S.T.).

CAUTION: We recommend charging DURACELL NiMH rechargeable batteries only. Do not attempt to charge non-rechargeable batteries. Misuse could cause batteries to rupture, causing personal injury or damage. Indoor use only. Dry location use only. Risk of electric shock. Never disassemble or alter any part of the charger or batteries. Charger or batteries may become hot during charging and will cool down when charging is complete. Not recommended for use by children.

IMPORTANT SAFETY INSTRUCTIONS:

1. SAVE THESE INSTRUCTIONS - This sheet contains important safety and operating instructions for this charger.
2. Before using battery charger, read all instructions and caution markings on the charger, battery and device using battery.
3. CAUTION - To reduce the risk of injury, charge only NiMH rechargeable batteries.
4. Do not charge Alkaline, Zinc Carbon, Lithium, NiOOH, or any batteries other than NiMH, as they may burst causing personal injury and damage.
5. Keep batteries away from fire or explosion may occur.
6. For proper insertion, please observe polarity indicators (+/-).
7. For indoor use only. Do not expose to rain or snow.
8. Do not place in or near water or extreme heat.
9. Do not operate charger with damaged cord or plug.
10. Do not operate charger if it has been severly damaged in any way.
11. Do not disassemble charger.
12. Disassembly may result in a risk of electric shock or fire.
13. To reduce the risk of electric shock, unplug the charger from the outlet when not in use.
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
15. This power unit is intended to be correctly oriented in a vertical or floor mount position.

OPERATING INSTRUCTIONS:

*If Flashing Red LED is encountered, first ensure you are attempting to charge a NiMH AA or AAA battery only. If yes, remove and reinsert the NiMH battery. If battery has become heated, it may be damaged. Insert a new NiMH battery.

TO CHARGE BATTERIES

1. Insert 2 AA or AAA DURACELL NiMH rechargeable batteries into the charging slot.
2. Plug in the charger to a power source.
3. If the connection is correct, the red LED will light to indicate that the charger is charging.

Condition:	LED:
Charging	Red
Completed charge	Green
Abnormal Battery or Abnormal Temperature	Flashing Red*

4. When all the batteries are fully charged, the green LED will light.
5. Now the batteries are ready to use, unplug the charger from the power outlet and remove the batteries.
6. If abnormal conditions are detected by the charger during charging, the charger will stop charging and the red LED will flash.

NOTES & USAGE TIPS:

1. New batteries may need to be charged before using.
2. Batteries will automatically stop charging when full charge is reached. Safety protections will prevent battery from overcharging.

Charging Time Table

Cell Capacity	Charging Time
2650 mAh	9 hours
2000 mAh	7 hours
1700 mAh	6 hours
1000 mAh	7 hours
800 mAh	6 hours

98984132